Chapter

9

Auto Dimensioning a Drawing

In this chapter, you will learn how to use the following AutoLISP functions to World Class standards:

- Adding Dimensions to a Drawing Automatically
- Starting the Rectangle_Shim Code
- Saving the Object Snap Settings and then Turning Them Off
- Using Getpoint to Obtain a Point on the Graphical Display
- Using Getreal to Obtain a Real Number from the Keyboard
- Creating Layers with the Visual AutoLISP Command Function
- Doing the Math in Visual AutoLISP
- Making Point Assignments in Visual AutoLISP
- Drawing in Visual AutoLISP
- Ending the Program
- Saving the Program
- Adding Dimension Centerlines to a Drawing
- Adding Linear Dimensions to a Drawing
- Adding a Diameter Dimension to a Drawing
- Loading the Program
- Running the Program

Adding Dimensions to a Drawing Automatically

In this chapter, we will venture to accomplish another level in drawing automation by having the program dimension of the part. We can achieve this goal by utilizing many of the same skills that we have learned in the previous chapters. We start out the drawing by creating a sketch, labeling the sketch, and writing the construction code to automatically create the part. What will be new in our code is a small section that will place center lines, horizontal and vertical dimensions and leaders that will denote the diameter of a hole. Once we understand the simplicity of adding dimensions on the dimensional layer then we will add them to our programs without hesitation and our drawings will be completed that much sooner.



Figure 9.1 – Sketch of the Rectangle shim

Step 1	Start the program
Step 2	Drawing setup
Step 3	User input
Step 4	Do the math
Step 5	Point assignments
Step 6	Lets draw
Repeat	Add dimensions
Steps 4-6	Math, Point Assignment, Draw Dimensions
Step 7	End the program

Figure 9.2 – Steps for Creating Dimensions in Construction Code

In Figure 9.3, we see a modification of the original sketch that includes points P1 through P8, and the X grid and Y grid designations. In our problem, we will place the dimensions 1 inch from the outside of the part. However, in future problems we can use a ratio to the part size to determine how for a dimension line should be from the perimeter of the part.



Figure 9.3 – Sketch with Points and X and Y Grid

Starting the Rectangle_Shim Code

Open the Visual LISP Editor and on the first line type the comment

;;; rectangle_shim.lsp

The program name is always on the first line of the code. The semicolons cause the statement to become a comment so the line of code will not be read.



Figure 9.4 – Starting the Rectangle_shim Program

The next comments in the program will be the details concerning what the routine will do. In this program, there are comments after almost every line of code.

Next we will create an AutoCAD Message by taking the information listed in the comments and placing the text in the **alert** function. On the first line of the alert expression, the program and the copyright information is keyed.

Add a new comment

;;; start the program

Then we start the program with the **defun** function, which means define function. Begin with the open parenthesis then **defun**, then a **c**: which will allow the program to run on the AutoCAD command line.



Figure 9.5 – Adding the Alert Expression

🕼 Visual LISP for AutoCAD <ch 9.="" dwg=""> - [rectangle_shim.LSP]</ch>	
🏷 Eile Edit Search View Project Debug Tools Window Help 🗕 d	F ×
1 1 2 2 2 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
] 73 77 7 4 4 4 20 60 70] 🛎 🗟 📾 🔬 🗞 🔅 (0) 🖓] 🖓 🤍 🖓 🖓 🚝 🕰 💟	
<pre>;;; rectangle_shim.lsp ;;; a program that draw a rectanxgular part with four holes</pre>	•
;;; copyright 2007 by charles robbins	
;;; charles robbins provides this code for your use. Use the code to your benefit ;;; and at your own risk. Charles Robbins does not guarantee that the code is error ;;; free in your application.	
(alert "rectangle_shim.lsp - copyright 2007 by Charles Robbins. Type Rect_shim to start")	
;;; Start the program	
(defun c:rect_shim (/)	
	~
Edit: E:/wcc lisp/Finished LISP problems/rectangle_shim.LSP * <_> (Visual LISP)	001

Figure 9.6 – The Defun Expression

Practice typing the following examples of the alert function at the command line of AutoCAD.

Function	Name	Description	
alert	AutoCAD Message	The alert function will create an AutoCAD message window appear on the graphical display with an OK button to close the message window.	
Examples			
At the beginning of the	(alert "Rectangle_shim.lsp -	Window appears on the graphical	
program	copyright 2007 by charles	display	
	robbins. type		
	Rectangle_shim to start")		
As an error prompt	(alert "Error: Type units in	Window appears on the graphical	
	inches")	display	

Next type Rect_shim which will be the execution symbol to start the program. Keep in mind

the alert message that stated "type Rect_shim to start". The alert message text and the **defun** symbol must match. The open and closed parenthesis "()"following the **Rect_shim** enclosing nothing means there will not be any defined arguments or local variables for this program. After that, we need to make changes to the AutoCAD System Variables that may interfere with the running of the code and automatically drawing the lines and arcs perfectly.

Practice typing the following examples of the defun function at the command line of AutoCAD.

Function	Name	Description
defun	Define Function	The define function leads off the beginning of the program
Examples		
Place a c: in front of the	(defun c:hello (/) (print "Hi	Answer: C:HELLO
program, hello. Allows	Ya All"))	Type: hello
hello to be typed at the		Returns: "Hi Ya All"
keyboard to execute the		
code		
When the code is used	(defun hello (/) (print "Hi	Answer: HELLO
inside another program,	Ya All"))	Type: (hello)
do not place the c: in front		Returns: "Hi Ya All"
of the program name		

Saving the Object Snap Settings and then Turning Them Off

In the next section of the code, we will turn off the drawing Object Snaps so they cannot possibly interfere with the insertion of the drawing notes. In order to accomplish this task, we you need to understand the getvar and the setvar functions. The getvar function will obtain a drawing setting, so we can save the number or text string for future use. The setvar function will allow us to change a system variable, like turning off the Object Snaps.

Start with a new comment

;;; drawing setup

And type the code

(setq	osm	(getvar
"osmod	e"))	

; gets osnap settings and assigns to osm

🛄 Visual LISP for AutoCAD <ch 9.dwg=""> - [recta</ch>	ngle_shim.LSP]	
🏷 Eile Edit Search Yiew Project Debug Tools 🛚	indow Help	_ 8 ×
1 2 2 3 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	💱 car 🕑 🌺 🔺 🖓 🕅	
つびデームムム 🖉 🍪 🎧 🛛 🛛 🖺	담 🔤 🔬 %% (*) 💭 🛛 📭 🖓 🖤 🖓 🖉 🚍 🕄 (?)	
;;; copyright 2007 by charles ro	bbins	^
<pre>;;; charles robbins provides this code for your use. Use the code to your benefit ;;; and at your own risk. Charles Robbins does not guarantee that the code is error ;;; free in your application. (alert "rectangle_shim.lsp - copyright 2007 by Charles Robbins. Type Rect_shim to start") ;;; start the program (defun c:rect_shim (/) ;;; drawing setup</pre>		
(setq osm (getvar "osmode")) (setvar "osmode" 0)	; gets osnap settings and assigns to osm ; turns osnap settings off	
<		>
Edit: E:/wcc lisp/Finished LISP problems/rectang	le_shim.LSP * <_> (Visual LISP) L 0	0020 C 00041

Figure 9.7 – Saving and Turning Off Object Snaps

Next, we will turn off the drawing's object snaps by setting the system variable "osmode" to 0 using this line of code. Add the comment as shown.

(setvar "osmode" 0) ; turns osnap settings off

Let's talk about the expression, (setq osm (getvar "osmode")). The function setq means set quotient and we will use the function to create a variable osm which stands for <u>object snap</u> mode, a variable name that we just made up. The variable osm will hold the integer representing the "osmode" system variable's setting. To get the number use the function getvar followed by the name of system variable inside a set of quotes.

To turn off a system variable in many cases in setting the variable to zero. In the expression, (setvar "osmode" 0), the function setvar followed by a system variable inside a set of quotes like "osmode" then a 0 will result in turning off the Object Snap settings.

Practice typing the following examples of the **setq**, **getvar** and **setvar** functions at the command line of AutoCAD.

Function	Name	Description
setq	Set Quotient	Allows the user to assign a real number, integer, string or list to a variable
Examples		
Set the variable a the text	(setq a "World Class CAD")	Answer: "World Class CAD"
string World Class CAD		
Set the variable counter	(setq counter 0)	Answer: 0
the integer 0		
Set the text height	(setq txtht 0.125)	Answer: 0.1250
variable txtht the real		
number 0.125		
Set the point variable sp	(setq sp (list 0.0 0.0 0.0))	Answer: (0,0,0)
the list of 0,0,0		

Function	Name	Description
getvar	Get a variable	Allows the user to obtain a system variable setting from an AutoCAD drawing
Examples		
Turn on the	(setq osm (getvar "osmode"))	Answer: 179
endpoint, midpoint,		
quadrant,		
intersection and		
perpendicular		
Object Snaps		
Get the AutoCAD	(setq osm (getvar "acadver"))	Answer: "16.2s (LMS Tech)"
version number		

Function	Name	Description
setvar	Get a variable	Allows the user to obtain a system variable setting from an AutoCAD drawing
Examples		
Turn off the Object	(setvar "osmode" 0))	Answer: 0
Snaps		

Using Getpoint to Obtain a Point on the Graphical Display

In the User Input section of the Construction Code, we need to expand into new areas besides just requesting the starting point and the getting a measurement using the getreal function as we did in the first eight programs.

The first function we will examine together is getpoint. This tool will allow the program user to select a point on the graphical display with their mouse. Following getpoint is a text string usually written is а commanding or questioning format.

Usual LISP for AutoCAD <ch 9.dwg=""> - [rectangle_shim.LSP]</ch>		
📎 File Edit Search Yiew Project Debug Tools Window Help		- 8 ×
🏙 😂 🖬 🎒 🏙 🕫 斗 👬 🍇 car 🔤 🌺 🚸 沙 沙 形		
み行 テデ ~ ~ ~ 急 砂 ゐ 📲 階 🔤 🌋 � 粂 🏟 🔍 🤍 🖓 🖉 🚍 😤	2	
		^
;;; Start the program		
(defun c:rect_shim (/)		
;;; drawing setup		
(seta osm (netuar "osmode")) • nets osnan settings and assigns to osm		
(setvar "osmode" 0) ; turns osnap settings off		
::: user input		
forte and forte the plant the standard and the		
(serd sp (gerpoint Anrick the starting point	11	
		>
Edit: E:/wcc lisp/Finished LISP problems/rectangle_shim.LSP * <_> (Visual LISP)	L 00025	C 00001

Figure 9.8 – Using the Getpoint Function

The user input of selecting a point begins with a comment.

;;; user input

Then type the following code:

(setq sp (getpoint "\nPick the starting point "))

We use the **setq** expression to assign the three point list (X, Y and Z) to the variable **sp** representing the starting point. After the function **getpoint**, a programmer has the option, in which we have chosen, to add a line of text prompting the user to "Pick the starting point" and we also modified the prompt in a small way. Notice that in front of the capital P in the word Pick, a "\n" is added. That will place the command "Pick the starting point" without containing those two characters to start on a new command line in the AutoCAD program. Placing command statements or questions on a new command line allows for a cleaner look to the user when following a command or answering the question.

Periodically we will work at an organization that wants their notes in the exact location of their drawing. When we face a programming problem such as this the starting point expression will change. First instance, let us make believe that the notes at this company start at the X and Y coordinates 14, 10. Then in this note making code, we would change the starting point expression to:

(setq sp (list 14 10 0))

This will place the beginning of the notes in an exact position for every occasion.

Practice typing the following examples of the **setq** and **getpoint** functions at the command line of AutoCAD.

Function	Name	Description
setq	Set Quotient	Allows the user to assign a real number, integer, string or list to a variable
Examples		
Set the variable a the text	(setq a "World Class CAD")	Answer: "World Class CAD"
string World Class CAD		
Set the variable counter	(setq counter 0)	Answer: 0
the integer 0		
Set the text height variable	(setq txtht 0.125)	Answer: 0.1250
txtht the real number		
0.125		
Set the point variable sp	(setq sp (list 0.0 0.0 0.0))	Answer: (0,0,0)
the list of 0,0,0		

Function	Name	Description
getpoint	Get a Point	Allows the user to obtain a point on the graphical display by selecting with a mouse
Examples		
Get a starting point	(setq sp (getpoint "\nPick	Answer:
	starting point"))	Pick starting point
		Then select a point and the will
		return a list like:
		(30.471 28.4052 0.0)

Using Getreal to Obtain a Real Number from the Keyboard

To ask the question, "What is the height of the rectangle_shim", we will use the **getreal** function. We use **getreal** to allow the LISP program user to type a number containing decimals with their keyboard. The **getreal** expression is set within the **(setq height)** code.

The information that the user types with the keyboard is stored in the variable name **height**. We will never pick a variable name that matches an AutoCAD command.

So type the following compound expression:

Usual LISP for AutoCAD <ch 9.dwg=""> - [rectangle_shim.LSP]</ch>	
🏷 Eile Edit Search View Project Debug Iools Window Help	_ & ×
🏙 🚔 🖶 🎒 🏙 🛍 🕫 🕶 🔺 📫 🎎 car 🚽 🌺 🔺 ルンス 形	
]️ੴ፹፫′∠∠੬惫ੴ◙ <mark>≌</mark> ቄ 重%%%()፼ ५ 박♀♥및 껲 ਵ ≅	2
;;; start the program	^
(defun c:rect shim (/)	
;;; orawing setup	
(setq osm (getvar "osmode")) ; gets osnap settings and assigns to osm (setvar "osmode" 0) ; turns osnap settings off	
;;; user input	
(setq sp (getpoint "\nPick the starting point	"))
(setq height (getreal "\nWhat is the height of the rectangle shim?	"))
(setq width (getreal "\nWhat is the width of the rectangle shim?	··))
(setq drillsize (getreal "\nWhat is the size of the drilled holes?	
(setd offset-y (getreal \nwhat is the offset of the dwilled hole on the y axis;	
(serd offset-x (gerreal (numat is the offset of the office note on the x axis:	
	~
	>
Edit: E:/wcc lisp/Finished LISP problems/rectangle_shim.LSP * <_> (Visual LISP)	L 00030 C 00001

Figure 9.9 – Using the Getreal Function

(setq height (getreal "\nWhat is the height of the rectangle_shim? "))

Whenever we are not quite sure whether the answer is going to be a whole number or a decimal, we will use the **getreal** function. Using another function which will only allow whole numbers will never allow the acceptance of a decimal.

If you look at the Visual LISP Editor in Figure 9.9, you will notice that we dressed the expressions so that the questions line up perfectly. You will pick up on this characteristic when the program is running and the typed answers to the questions line up neatly.

Practice typing the following examples of the **getreal** function at the command line of AutoCAD.

Function	Name	Description
getreal	Get a Real Number	Allows the user to obtain a real number by allowing the user to type at the keyboard
Examples		
Get a number	(setq txtht (getreal "\nWhat	Answer:
	is the text height?"))	What is the text height?
		Then type: 0.125
		3.2
Ask for a number, user	(setq txtht (getreal "\nWhat	Answer:
types a whole number and	is the text height?"))	What is the text height?
the reply is changed to a		Then type: 1
real number		1.0
Ask for a number, user	(setq txtht (getreal "\nWhat	Answer:
types a fraction and the	is the text height?"))	What is the text height?
reply is changed to a real		Then type: 1/8
number		0.125

Creating Layers with the Visual AutoLISP Command Function

In all of the other Visual AutoLISP programs, we run the code on the layer that we want to have the orthographic view or notes. In this detail, we will place the entities on unique layers such as footer, block, wood, dimension and text. Then we will lame addition layers for center, hidden and section lines.

;;; user input		
setq sp setq height setq width setq drillsize setq offset-y setq offset-x	(getpoint "\nPick the starting point (getreal "\nWhat is the height of the rectangle shim? (getreal "\nWhat is the width of the rectangle shim? (getreal "\nWhat is the size of the drilled holes? (getreal "\nWhat is the offset of the drilled hole on the y axis? (getreal "\nWhat is the offset of the drilled hole on the x axis?	
;;; setup layers		
(command "layer'	"n" "rectangle_shim" "c" "14" "rectangle_shim" "")	
(command "layer"	"N" "dimension" "C" "red" "dimension" "")	
(command "layer'	"n" "center" "c" "uellow" "center" "lt" "center" "center	an internet
(command "layer'	"n" "hidden" "c" "magenta" "hidden" "lt" "hidden" "hidden	
(command "layer"	"n" "section" "c" "cyan" "section" "lt" "phantom" "sectio	(n'' ''')

Figure 9.10 – Creating Layers in AutoLISP

An easy way to make a layer for a detail is to use the command function and to follow the creating a new layer process. This can be harder for individuals just newly training with AutoCAD, since many computer aided design tools are now in dialogue boxes and we cannot easily view all the options that are available with a command function. We will share the most common options in the table below.

Command Layer Function	Command Layer Function
(command "layer" "n" "plate" "")	Makes a new layer named "plate"
(command "layer" "c" "8" "plate" "")	Sets the layer color to "color 8" for layer named "plate"
(command "layer" "lt" "center" "center" "")	Sets the layer linetype to "center" for
	layer named "center"
(command "layer" "s" "plate" "")	Sets the current layer as "plate"
(command "layer" "f" "plate" "")	Freezes the layer named "plate"
(command "layer" "t" "plate" "")	Thaws the layer named "plate"
(command "layer" "on" "plate" "")	Turns the layer named "plate" on
(command "layer" "off" "plate" "")	Turns the layer named "plate" off
(command "layer" "lo" "plate" "")	Locks the layer named "plate"
(command "layer" "u" "plate" "")	Unlocks the layer named "plate"

We can combine layer options such as new and color and create a command line expression that will both create a new layer and set the color for that layer. When we use the color option "c", the next item is the name or number of the color, followed by the name of the layer. To end the layer command expression, place an open and closed quote "" at the end of the code and then a closed parenthesis.

Type the following lines in the rectangle_shim program.

;;; setup layers

(command "layer" "n" "rectangle_shim" "c" "14" " rectangle_shim "	
(command "layer" "n" "dimension" "c" "red" "dimension"	
(command "layer" "n" "text" "c" "green" "text"	

Now we will make the center, hidden and section layers in the routine. We may be using different colors or layer names than what your organization uses, so feel to free to make changes to the layer name or color that defines your group's standard layers. changes

Usual LISP for AutoCAD <drawing1.dwg> - [wallsection.LSP]</drawing1.dwg>		×
🏷 Eile Edit Search View Project Debug Iools Window Help	- 8	×
111 😂 🖬 🚭 🌬 🗠 🗠 🔺 □, 🖤 🖓 🎔 🖓 💯 🚝 😫 😰] ひかす ムム 台	66	ò
📑 🖼 🖬 🔬 🛠 🗯 (e) 📰 🔄 🏘 🎎 car 🔤 🙀 🦽 🐼 🗵 76		
		^
(setq wallht (getreal "\nWhat is the wall height?	")) —	
;;; setup layers		
(command layer 'n 'footer' 'C' '8' 'footer'		
(command layer in block come block block		
(command flayer no wood contraction for the wood		
(command layer in dimension c red dimension		
(command "layer" "n" "text" "c" "green" "text"		
(command "layer" "n" "center" "c" "yellow" "center" "lt" "center" "center")	
(command "layer" "n" "hidden" "c" "magenta" "hidden" "lt" "hidden" "hidden")	
(command "layer" "n" "section" "c" "cyan" "section" "lt" "phantom" "section)	_
		~
	>	
Edit: C:/Documents and Settings/Dad/Desktop/Visual AutoLISP Programs/wallsection.LSP * < > fVis L 00063	C 000)01

Figure 9.11 – Creating Layer with Special Linetypes

If the layer name, color and linetype already exists in the drawing, nothing will change when these lines of code execute.

Type the following lines in the rectangle_shim program.

(command "layer" "n" "center" "c" "yellow" "center" "lt" "center" "center" "") (command "layer" "n" "hidden" "c" "magenta" "hidden" "lt" "hidden" "hidden" "") (command "layer" "n" "section" "c" "cyan" "section" "lt" "phantom" "section" "")

Doing the Math in Visual AutoLISP

Now, we will return back to the middle of the program and finish the math section of the code. Again the setq function is the choice for assigning values to the variables X1, X2, X3, X4, Y1, Y2, Y3 and Y4.

The **car** function is used with variable **sp** (the starting point) to extract the x-coordinate of the starting point list. If the starting point is (4, 3, 0)then **(car sp)** will return as 4 and be assigned to the variable X1. So the **car** function returns the first number in the list.

rectangle_shim.LSP					
;;; user input					~
(setq sp (getpoint "\nPick th	e starting poin	t			
(setg height (getreal "\nWhat is	the height of t	he rectangle sh	im?	"))	
(setq width (getreal "\nWhat is	the width of th	e rectangle shi	m?		
(setq drillsize (getreal "\nWhat is	the size of the	drilled holes?		"))	
(setq offset-y (getreal "\nWhat is	the offset of t	he drilled hole	on the y	axis? "))	1.00
(setq offset-x (getreal "\nWhat is	the offset of t	he drilled hole	on the x	axis? "))	
;;; setup layers					
(command "layer" "n" "rectangle_shim	" "c" "14"	"rectangle_shi	m)		
(command "layer" "n" "dimension"	"c" "red"	"dimension")		
(command "layer" "n" "text"	"c" "green"	"text")		
(command "layer" "n" "center"	"c" "yellow"	"center" "lt"	"center"	"center" "")	
(command "layer" "n" "hidden"	"c" "magenta"	"hidden" "lt"	"hidden"	"hidden" "")	
(command "layer" "n" "section"	"c" "cyan"	"section" "lt"	"phantom"	"section" "")	
;;; do math					
(seto x1 (car sp)					
x2 (+ x1 offset-x)					
x4 (+ x1 width)					
x3 (- x4 offset-x)					

Figure 9.12 – Defining the X-Ordinates

That explains the use of **car** to find the coordinates x1, now we have to continue down the X grid to obtain value for x2. To obtain the x2 coordinate, use the addition function + to add **offset-x** to the x1 value.

Type the following lines in the rectangle_shim program using the sketch in Figure 9.2 to find the X ordinate the dimension that defines the horizontal measurements.

;;; math

```
(setq x1 (car sp)
x2 (+ x1 offset-x)
x4 (+ x1 width)
x3 (+ x4 offset-x)
)
```

Likewise. the cadr function is used with variable **sp** (the starting point) to extract the ycoordinate of the starting point. Again, if the starting point is (4, 3, 0)then (cadr sp) will return as 3 and be assigned to the variable y1. So the cadr returns function the second number in the list.

rectangle_shim.LSP					
;;; setup layers					2
(command "layer" "n" "rectangle_shim" (command "layer" "n" "dimension" (command "layer" "n" "text" (command "layer" "n" "center" (command "layer" "n" "hidden"	"c" "14" "c" "red" "c" "green" "c" "yellow" "c" "magenta"	"rectangle_shim "dimension" "text" "center" "lt" "hidden" "lt"	""") "") "center" "hidden"	"center" "") "hidden" "")	
(command "layer" "n" "section"	"c" "cyan"	"section" "lt"	"phantom"	"section" "")	
<pre>(setq x1 (car sp)</pre>					
ý2 (+ y1 offset-y) y4 (+ y1 height) y3 (- y4 offset-y))					
					2

Figure 9.13 – Defining the Y-Ordinates

To find the value for the adaptable y_2 , we add the variable for the **offset-y** height. We use the adding LISP function + to make the expression

y2 (+ y1 offset-y)

Type the following lines in the rectangle_shim program using the sketch in Figure 9.2 to find the Y ordinate the dimension that defines the vertical measurements.

```
(setq y1 (cadr sp)
y2 (+ y1 offset-y)
y4 (+ y1 height)
y3 (+ y4 offset-y)
```

Making Point Assignments in Visual AutoLISP

One of the easiest sections of code for a new or experienced programmer to accomplish is the point assignments, where one assigns X and Y coordinates to the point vertexes. Basically, we did the work when we made the Rectangle_shim sketch.

rectangle_shim.LSP	
;;; 00 math	
(setq x1 (car sp)	
x2 (+ x1 offset-x)	
x4 (+ x1 width)	
x3 (- x4 offset-x)	
)	
(setq y1 (cadr sp)	
y2 (+ y1 offset-y)	
y4 (+ y1 height)	
y3 (- y4 offset-y)	
)	
;;; point assignments	
(seta n1 (list x1 u1))	
n2 (list x4 u1)	
p3 (list x4 u4)	
p4 (list x1 u4)	
p5 (list x2 u2)	
n6 (list x3 µ2)	
p7 (list x3 u3)	
p8 (list x2 u3)	
1 and a standard and and and and	

Figure 9.14 – Defining the Point Assignments

When we define the points for the footer, remember when we read that coordinate P1 is (X1, Y1). P2 is (X4, Y1). P3 is (X4, Y4). P4 is (X1, Y4). Now we write a **setq** expression setting these grids coordinates to the points **p1**, **p2**, **p3**, **p4** through **p8**.

The **list** function can create an X, Y and Z coordinate by typing the appropriate X and Y values after the function name. We do not need to add the Z coordinate if the value is going to be zero. (See Figure 9.14)

Type the following lines in the rectangle_shim program using the sketch in Figure 9.2 to find the X and Y coordinate for each point.

; point assignments

```
(setq p1 (list x1 y1)

p2 (list x4 y1)

p3 (list x4 y4)

p4 (list x1 y4)

p5 (list x2 y2)

p6 (list x3 y2)

p7 (list x3 y3)

p8 (list x2 y3)
```

Drawing in Visual AutoLISP

Before drawing the first line in the Rectangle_shim detail, we will set the current layer as "rectangle_shim". Before we draw an entity using the command functions of line, pline and arc tools, we will continually place the article on the precise drawing layer. Type the following code to set the current layer to "rectangle_shim".

```
(command "layer" "s" "rectangle shim" "")
```

Now that the layer is set to rectangle shim, we will proceed to draw the part which has four points. automatically When drawing any entity in AutoCAD, the programmer uses the command function which evokes anv AutoCAD standard command.

Oldeh ud ud N	
(list x4 u1)	
(list x4 y4)	
(list x1 u4)	
(1ist x2 u2)	
(list x3 y2)	
(list x3 u3)	
(list x2 u3)	
ets draw	
"layer" "s" "rectangle_shim" "") ; sets layer to the rectangle_shim layer	
	100
	×
	<pre>(list x4 y4) (list x1 y4) (list x2 y2) (list x2 y2) (list x3 y3) (list x2 y3) ets draw "layer" "s" "rectangle_shim" "") ; sets layer to the rectangle_shim layer</pre>

Figure 9.15 – Setting a Rectangle_shim Layer as Current

We have to state this rule, since ARX commands typed at the command line like Render or Rotate3D need to be executed differently, which we did in Chapter 6 with the **saveing** function. After the **command** function is typed, the command "line" follows in quotes, then by the point vertexes **p1 p2 p3 p4** of the part and finally "**c**" to close the polygon.

Type the following code:

;;; lets draw

(command "line" p1 p2 p3 p4 "c")

То have four circles drawn inside the shim composing of four lines, we will use the circle command. The next argument is to list the center point of the circle which is the point vertex, p5, p6, p7 and p8, and finally to describe the diameter of the circle by requesting the diameter with the text "d" and the real number representing diameter the in the variable drillsize.

rectangle	_shim.LSP	
;;; point	assignments	
(setq p1	(list x1 y1)	
p2	(list x4 y1)	
p3	(list x4 y4)	
p 4	(list x1 y4)	
p5	(list x2 y2)	
рó	(list x3 y2)	
p7	(list x3 y3)	
p8	(list x2 y3)	
,, I	ets draw	
command	"lower" "e" "weetongle chim" "") , cate lower to the weetongle chim lower	
command	"line" of og og ok 'e")	
command	The pi pa po pe c p	
command	circle ps d diffsize)	
command	reirele no "d" drilsize)	
command	circle" ng 'd' drilsize)	
Commund	circle po a difficie,	

Figure 9.16 – Draw the Four Lines

All of this is brought to together with the following expression.

(command "circle" p5 "d" drillsize)

Ending the Program

To end the program, we will set the object snap mode back to the original settings by using the **setvar** function followed by the variable **osm** which holds the original integer containing the Osnap settings. Type the following code.

(setvar "osmode" osm)



Figure 9.17 – End of Program

To end the program, we will need to place a parenthesis at the end of the code to close the **defun c:nm** function. Type the following code.

(princ)

)

The **princ** function used in this routine will allow the program to end without printing the last line of the program to the command line. Without this function the command line can show a number or text that may not make sense to the use. This function is used to keep your code neat.

Practice typing the following examples of the **princ** function at the command line of AutoCAD.

Function	Name	Description
princ	Princ Function	Will allow the program to run without printing the last line of the code to the command line
Example		
Typing an expression at	(setq a "Hello")	Answer: "Hello"
the command line without		
the princ function		
Typing an expression at	(setq a "Hello")(princ)	Answer: nothing
the command line without		
the princ function		

Saving the Program

Now that the program is finished, we need to double check our typing with the text in this manual and then save our program to our folder named "Visual AutoLISP Programs".

Make sure the Look in list box is displaying the LISP Visual Programs folder and then select the program "rectangle shim" and press the Load button. At the bottom – left corner of the Load / Unload Applications window you will see a small text display that was blank initially but now displays the text as shown in Figure 9.18,

"rectangle_shim.LSP successfully loaded"

After noting that the program is loaded, press the Close button and now when you are in the AutoCAD program, an AutoCAD message window appears in the middle of the graphics display. The copyright and information to start the program is shown.



Figure 9.18 – Loading the Rectangle_shim Program



Figure 9.19 – The Alert Message

At World Class CAD, we will run the program as written and correct any errors that we find in creating the part, so that when we add the dimension code, we already know that the initial program is error free.

Now we will add the dimensions.

Adding Dimension Centerlines to a Drawing



Figure 9.20 – Setting the Dimension Layer

To place a center mark on a circle, we will select the circle by placing the pick box on the entity. We will accomplish this task by building a new point from the center of a circle. We will start with the first circle and the centerpoint P5. The new point will have an X ordinate that is half of the drillsize and the Y ordinate that is the same as P5. We will assign the new point to the variable **circlept**. Write the following code.

```
(setq circlept (list (+ (car p5) (/ drillsize 2.0)) (cadr p5) ))
```

To place the center mark, type the following code.

(command "dimcenter" circlept)

Each time the variable **circlept** will be redefined for the other holes, P6, P7 and finally P8. Type the following lines of code.

```
(setq circlept (list (+ (car p6) (/ drillsize 2.0)) (cadr p6) ))
(command "dimcenter" circlept)
(setq circlept (list (+ (car p7) (/ drillsize 2.0)) (cadr p7) ))
(command "dimcenter" circlept)
(setq circlept (list (+ (car p8) (/ drillsize 2.0)) (cadr p8) ))
(command "dimcenter" circlept)
```

We continue to arrange similar lines of code as shown in figure 9.21, so the syntax of the program is simple to check. We can easily spot errors in these programming expressions since they are aligned.

Wisual LISP for AutoCAD <drawing3.dwg> - [rectangle_shim.LSP]</drawing3.dwg>	
🏷 Eile Edit Search View Project Debug Iools Window Help	- 8 ×
」 🏙 📽 🖬 🔮 🖇 🛍 🛍 🕫 🕶 🔺 🛛 👭 🍇 car 🔤 🙀 🔺 沙 沙 沙	
]] 俄 衍 亓 스 스 台 创 &	2
;;; dimension the drawing	~
(command "lawer" "c" "dimension" "") • sets lawer to the dimension lawer	
(setq circlept (list (+ (car p5) (/ drillsize 2.0)) (cadr p5)))	
(command "dimcenter" circlept) (setq circlept (list (+ (car p6) (/ drillsize 2.0)) (cadr p6)))	
<pre>(command "dimcenter" circlept) (setg circlept (list (+ (car p7) (/ drillsize 2.0)) (cadr p7)))</pre>	
(command "dimcenter" circlept)	
<pre>(setq circlept (list (+ (car p8) (/ drillsize 2.0)) (cadr p8))) (command "dimcenter" circlent)</pre>	
	~

Figure 9.21 – Inserting Dimension Center Marks

Adding Linear Dimension to a Drawing

When we add the linear dimensions, first we will reset the dimension extension offset, dimexo, so that the dimension extension lines do not overlap the center marks. Before changing the system variable, we will save the old setting to the variable **offorigin**. For this drawing, we will set the new dimension extension line offset to 0.1875. Type the following lines of code.

(setq offorigin (getvar "dimexo")) (setvar "dimexo" 0.1875)

When we dimension with linear dimensions, we select two points that represent the linear distance we wish to measure. The third point selection is to place the dimension. We are going to select the points defined in the sketch shown in figure 9.2. For our third point, we will create a new point with the **list** function that is one inch off the part's perimeter. We will add one inch to the X ordinate to place the dimension on the right side of the part. We will subtract one inch to the X ordinate to place the dimension on the left side of the part. We will subtract one inch to the X ordinate to place the dimension on the left side of the part. We will subtract one inch to the X ordinate to place the dimension on the left side of the part. We will subtract one inch to the Y ordinate to place the dimension on the left side of the part. We will subtract one inch to the Y ordinate to place the dimension on the left side of the part. We will subtract one inch to the Y ordinate to place the dimension on the left side of the part. We will subtract one inch to the Y ordinate to place the dimension on the left side of the part. We will subtract one inch to the Y ordinate to place the dimension on the left side of the part. We will subtract one inch to the Y ordinate to place the dimension on the left side of the part.

Type the following lines of code.

```
(command "dimlinear"
(command "dimlinear"
(command "dimlinear"
(command "dimlinear"
(command "dimlinear"
```

To force a horizontal or vertical dimension, use the old AutoCAD command "dimhorizontal" or "dimvertical". When we originally tested this program, the dimension from P5 to P1 was being placed horizontally. We will use the dimvertical command to place the last linear dimension. Type the following code.

(command "dimvertical" p5 p1 (list (- (car sp) 1.0)(cadr sp))) p5 p6 (list (car p1) (- (cadr p1) 1.0))) p5 p1 (list (car p1) (- (cadr p1) 1.0))) p2 p3 (list (+ (car p2) 1.0) (cadr p2))) p2 p3 (list (car p1) (- (cadr p1) 1.0))) p4 p3 (list (car p4) (+ (cadr p4) 1.0))) p5 p8 (list (- (car sp) 1.0)(cadr sp)))





Adding a Diameter Dimension to a Drawing

Now add a diameter dimension to the drawing by selecting the circle in the upper left hand corner of the drawing and placing the dimension in the same quadrant, one inch off the perimeter. We use the same list code to pick the circle and created a second point place to the diameter text.

Type the following code.

U Visual LISP for AutoCAD <drawing3.dwg> - [rectangle_shim.LSP]</drawing3.dwg>	
🏷 Eile Edit Search View Project Debug Tools Window Help	- 8 ×
」 🎦 🚔 🛃 🎒 隆 🕫 🕿 🕫 🔺 🗍 🏘 🎼 car 🔤 🙀 🔺 沙 沙 沙	
] 79 77 77 − − − − − − − − − − − − − − −	2
;;; dimension the drawing	~
(command "layer" 's" "dimension" ") ; sets layer to the dimension layer	
(command "dimcenter" circlent)	
(setq circlept (list (+ (car p6) (/ drillsize 2.0)) (cadr p6)))	
(command "dimcenter" circlept)	
(setq circlept (list (+ (car p7) (/ drillsize 2.0)) (cadr p7)))	
(command "dimeenter" circlept)	
(sett tirtiept (iist (* (tar ps) (/ urilisize 2.8)) (taur ps)))	
(seta offorigin (getuar "dimexo"))	
(setvar "dimexo" 0.1875)	
(command "dimlinear" p5 p6 (list (car sp) (- (cadr sp) 1.0)))	
(command "dimlinear" p5 p1 (list (car sp) (- (cadr sp) 1.0)))	
(command "dimlinear" p2 p3 (list (+ (car p2) 1.0) (cadr p2)))	
(command "dimlinear" p4 p3 (list (car p4) (+ (cadr p4) 1.0)))	
(command "diminhear" p5 p8 (list (- (car sp) 1.0)(cadr sp)))	
(command "dimetander" (list (+ (car sk) // drillsize 2 8)/(cadr sk)) (list (-	(car oh
(command armanameter (fist (. (car po) () arffistze z.o))(can po)) (fist ((cu p+
;;; end of program	-
	×

Figure 9.23 – Inserting a Diameter Dimension

(command "dimdiameter" (list (+ (car p8) (/ drillsize 2.0))(cadr p8)) (list (- (car p4) 1.0)(+ (cadr p4) 1.0)))

Save the drawing and run the program which will draw and dimension the part.

Running the Program

Press the OK button if you agree with the message and follow your own instructions by typing **Rectangle_shim** at the command line. The message "Pick starting point" appears on the command line and then we should select a point at the lower left hand corner of the AutoCAD graphics display.

After selecting a starting point, we will be prompted by the program with four questions, and each will require a number for the answer.

Command: rect_shin	n
Pick the starting	point
20.2602, 19.5111, 0.0000	SNAP GRID ORTHO POLAR OSNAP



The first question is "what is the height of the rectangle shim" and to test the program we will type "4". The next question is "what is the width of the rectangle shim" and we will input "6". The next prompt is "what is the size of the drilled holes" and we will type "0.5". the next two

inquiries are "what is the offset of the drilled hole on the y axis" and "what is the offset of the drilled hole on the x axis" and we will type 0.5 for both.



Figure 9.25 – Testing the Program

* World Class CAD Challenge 04-20* - Within two hours, create a new AutoCAD file and then open the Visual AutoLISP editor and code the problem using the construction coding method. Save the code the problem as rectangle_shim.lsp.

Send your copy of your code for verification to the authors of these problems to have your name and location posted. See the web site for instructions at

www.worldclasscad.com

There are addition exercises for text based routines in the appendixes of this manual. Written below is the entire rectangle_shim.LSP code for your benefit.

- ;;; rectangle_shim.lsp
- ;;; a program that draw a rectangular part with four holes
- ;;; copyright 2007 by charles robbins
- ;;; charles robbins provides this code for your use. Use the code to your benefit
- ;;; and at your own risk. Charles Robbins does not guarantee that the code is error
- ;;; free in your application.

(alert "rectangle_shim.lsp - copyright 2007 by Charles Robbins. Type Rect_shim to start")

;;; start the program

(defun c:rect_shim (/)

;;; drawing setup

```
(setq osm (getvar "osmode"))
(setvar "osmode" 0)
```

; gets osnap settings and assigns to osm ; turns osnap settings off

```
;;; user input
```

(setq sp(getpoint "\nPick the starting point"))(setq height(getreal "\nWhat is the height of the rectangle shim?"))(setq width(getreal "\nWhat is the width of the rectangle shim?"))(setq drillsize(getreal "\nWhat is the size of the drilled holes?"))(setq offset-y(getreal "\nWhat is the offset of the drilled hole on the y axis?"))(setq offset-x(getreal "\nWhat is the offset of the drilled hole on the x axis?"))

```
;;; setup layers
```

```
(command "layer" "n" "rectangle_shim" "c" "14"
                                                    "rectangle_shim" "")
(command "layer" "n" "dimension"
                                        "c" "red"
                                                    "dimension"
                                                                     "")
(command "layer" "n" "text"
                                         "c" "areen" "text"
                                                                  "")
                                         "c" "yellow" "center" "lt" "center" "center" "")
(command "layer" "n" "center"
(command "layer" "n" "hidden"
                                         "c" "magenta" "hidden" "It" "hidden" "hidden" "")
(command "layer" "n" "section"
                                         "c" "cyan" "section" "It" "phantom" "section" "")
;;; do math
(setq x1 (car sp)
   x2 (+ x1 offset-x)
   x4 (+ x1 width)
   x3 (- x4 offset-x)
)
(setq y1 (cadr sp)
   y2 (+ y1 offset-y)
   y4 (+ y1 height)
   y3 (- y4 offset-y)
)
;;; point assignments
(setq p1 (list x1 y1)
   p2 (list x4 y1)
   p3 (list x4 y4 )
```

```
p4 (list x1 y4)
p5 (list x2 y2)
p6 (list x3 y2)
p7 (list x3 y3)
p8 (list x2 y3)
```

;;; lets draw

```
(command "layer" "s" "rectangle_shim" ""); sets layer to the rectangle_shim layer
(command "line" p1 p2 p3 p4 "c")
(command "circle" p5 "d" drillsize)
(command "circle" p6 "d" drillsize)
(command "circle" p7 "d" drillsize)
(command "circle" p8 "d" drillsize)
;;; dimension the drawing
(command "layer" "s" "dimension" "") ; sets layer to the dimension layer
(setq circlept (list (+ (car p5) (/ drillsize 2.0)) (cadr p5) ))
(command "dimcenter" circlept)
(setg circlept (list (+ (car p6) (/ drillsize 2.0)) (cadr p6) ))
(command "dimcenter" circlept)
(setq circlept (list (+ (car p7) (/ drillsize 2.0)) (cadr p7) ))
(command "dimcenter" circlept)
(setg circlept (list (+ (car p8) (/ drillsize 2.0)) (cadr p8) ))
(command "dimcenter" circlept)
(setg offorigin (getvar "dimexo"))
(setvar "dimexo" 0.1875)
(command "dimlinear" p5 p6 (list (car sp) (- (cadr sp) 1.0)))
(command "dimlinear" p5 p1 (list (car sp) (- (cadr sp) 1.0)))
(command "dimlinear" p2 p3 (list (+ (car p2) 1.0) (cadr p2)))
(command "dimlinear" p4 p3 (list (car p4) (+ (cadr p4) 1.0)))
(command "dimlinear" p5 p8 (list (- (car sp) 1.0)(cadr sp)))
(command "dimvertical" p5 p1 (list (- (car sp) 1.0)(cadr sp)))
(command "dimdiameter" (list (+ (car p8) (/ drillsize 2.0))(cadr p8)) (list (- (car p4) 1.0)(+
(cadr p4) 1.0 )))
;;; end of program
(command "layer" "s" "0" "")
(command "zoom" "e")
(setvar "osmode" osm)
(setvar "dimexo" offorigin)
;(gc)
(princ)
)
```