

# PRO-ENGINEER WILDFIRE REFERENCE GUIDE

CONSTRAINED

ASSEMBLY

## Constrained



PARTNAME.PRT



This symbol in an assembly means the part is not fully constrained in assembly