


# PRO-ENGINEER WILDFIRE REFERENCE GUIDE

Regenerate drawing part and / or assembly

REGENERATE



Click on icon to “regenerate”

“Regenerates” model or drawing to changes made