

PC Hardware – X86 IRQ Chart

IRQ	Address	Used for
0		System Timer
1		Keyboard
2		Cascade for IRQ 9
3	02F8-02FF	COMM 2
	02E8-02EF	COMM 4
4	03F8-03FF	COMM 1
	03E8-03EF	COMM 3
5	0278	Sound Card or LPT2
6		Floppy Disk Controller
7	0378	LPT1
8		Real Time Clock
9		Cascade for IRQ 2
10		Available (used by PCI expansion slot)
11		Available (used by SCSI adapters)
12		Available (used by PS2 mouse)
13		Math co-processor
14		Primary Hard Drive
15		Secondary Hard Drive