## PRO-ENGINEER WILDFIRE REFERENCE GUIDE

**BEND ALLOWANCE** 

**BEND TABLE** 

## **BEND ALLOWANCE**

Bend allowances will need to change when a metal part is changed from one metal to another.

Example when "value engineering" a metal part you may want to change the part from stainless steel to cold rolled steel or aluminum. You may need to change the part from aluminum.

